

Wheel and Rim Protector Design Drawing: Figure 1 (Front View)




Wheel and Rim Protector outer piece



Wheel and Rim Protector Interconnector




Standard Rim



Rim with Wheel and Rim Protector Installed

Wheel and Rim Bumper Side View: Outer and Inner Piece with connector



Connector designed to attach outter bumper to rim

Connector designed to attach Inner Piece to rim

Enlarged Connectors